
Combi-Can

MOUNTING CUTOUT

#7432 Installation Instructions:



- Retrofits standard ¾" cam hole
- Cam can be placed in 180 degree increments (or 90 degrees with dual hole cams)
- · Cam lock can be installed vertically or horizontally
- 1. Insert lock body through front of 3/4" drilled hole
- Note clear, distinct open and close indicators on front of lock. Knob will be turned to 'open' to release lock.
- 3. Thread cylinder nut and tighten
- Attach 90 degree stop cam (note that stop cam needs to be placed in position shown in image to right).
- 5. Attach cam (straight or offset) onto back of lock body
- 6. Secure with nut and nut washer.



Correct stop cam placement in closed position

Setting Your Own Combination:

- The combination is factory set at all 0's
- · Combination must be on opening number prior to resetting.
- On top of lock is code reset button. Press and keep pressed down reset button.
- Set your personal combination by turning dials to desired combination.
- Release reset button and your combination is set.
- To lock, rotate one or more dials after lock is closed.
 To open lock, turn dials to your personal combination.

Unlocking Cam Lock Using Key:

· Insert key into lock, rotate key clockwise to unlock symbol

Discovering Combination Using Key & Code Retrieve Pin:

- Open the combination cam lock with master key
- Rotate lock head clockwise to unlock
- · Uninstall cam lock from door
- Using code retrieve pin, insert pin in top small hole located back of lock body (see image to right).
- Turn top dial until you feel retrieve pin descend into dial and dial will no longer turn – discovering current combination for top dial
- · Repeat these steps for remaining three dials
- Combination can now be reset if desired



www.combi-cam.com

Innovative, Quality Security Solutions

www.fimsecurity.com

©2010 FJM Security Products