

## Securiproduct Power Supply 12-16Vac - Wiring Instructions



**1. For 12V: Connect 12V + 0V**

**2. For 16V: Connect 16V + 0V**

WARNING: DO NOT BRIDGE 16V with 12V

