



D.A.C.E. UNIVERSAL CONTROL BOARD

The following instructions show how to connect the D.A.C.E. Universal Control Board

The operation of the motor remains the same as described in the manual.

The difference is mainly in the lay-out of the board. All the wiring remains the same. Programming remains the same.



Charger Wiring.

The wiring from the transformer to the charger must be done using a minimum of 0.5mm cable

Do not use communication cable.

Do not put 220 Volt AC directly on to the board.

Ensure that all cable is run in a conduit.

