

I. Manufacturer combination

1. Manufacturer combination code set at 0-0-0-0.

II. Reset

- Make sure the knob stays at position. Turn the combination to correct codes.
- 2. Push down and hold the reset button(as Fig. 1) until you have done the new code resetting. Turn the 4 wheels to your desired new combination position and release the reset button.
- 3. Turn the knob to " a -opening position. Congratulation! You have done the new code resetting.
- Random your key codes.





III. How to unlock and retrieve combination codes if you forget the combination.

- a. Insert the key to turn the knob to opening position. (You also can use key function only to unlock/lock).
- b. Retrieve combination codes
 - i) Insert a paperclip into the first combination research hole (as Fig. 2) and turn the contrast wheel until it cannot be moved.
 - ii) Key codes retrieve way of the rest three combinations may be deducted by analogy.
 - iii) If you found all all codes back, please make sure the knob is able to turn by hand.




Fig. 2