

Wiring and Installation

- 1. Fix the hole of bracket with wall hole.
- 2. Connect Room station cables as appeared in the figure below.
- 3. Put the door unit inside of a back box as shown in the figure below.
- 4. Connect Door Release cable as appeared in the figure below.
- 5. Place the unit on the wall and mount with screws supplied.





Specification

Model No. Rated voltage/Power consumption	DR-201A / 201AG Supplied from Room Unit
Installation	Flush mounted type
Dimension	117 X 195 X 16mm
Operating Temp.	-10°C ~ +50°C