









HOW TO INSTALL THIS DEADBOLT LOCK

1 MARK DOOR	2 BORE HOLES	3 INSTALL DEADBOLT	4 INSTALL CYLINDER	5 ATTACH INSIDE TRIM
<p>TEMPLATE</p>  <ul style="list-style-type: none"> Mark site of lock and bore. 	<p>BASE</p>  <p>HOLE</p> <ul style="list-style-type: none"> Bore the holes through door. ... Cut out base. 	 <p>DEADBOLT</p> <ul style="list-style-type: none"> Keeping the arrow sign in the deadbolt always upward. 	<p>CAM</p>  <p>TORQUE BAR</p> <ul style="list-style-type: none"> Keeping cylinder torque bar horizontally insert in to cam slot. 	
<p>6 INSTALL STRIKE</p>  <p>STRIKE</p> <p>Line of door thickness</p>	<p>DOUBLE CYLINDER</p>  <ul style="list-style-type: none"> PREPARE DOOR EXACTLY AS IN STEPS 1-5 AND 6 ABOVE. INSTALL INSIDE CYLINDER keeping cylinder torque bar vertically insert in to cam slot. SAME AS STEP 4 ABOVE. 		<p>INSTRUCTION FOR ADJUSTABLE DEADBOLT</p>  <p>Press the end of the deadbolt. Turn the latchover pull or push, make backset become 70mm (2 3/4") for 60mm (2 3/8").</p> <p>60mm (2 3/8") 70mm (2 3/4")</p>	

